


The Outdoor Blind is the modern alternative for enclosing your patio. The hi-tech fabrics are specifically formulated and manufactured to withstand the suns harmful UV rays while protecting your furniture. Lower and raise the blind using a removable crank handle or motorise your blind.







REFLECT YOUR STYLE

The blind is secured at the bottom with a selection of hold down clips, which allows the blind to remain down during windy weather. You can also select a Channel X Blind that is fully enclosed on the top and sides. The Outdoor Blind will allow you maximum use of your external entertainment areas by stopping heat and glare and also providing a degree of weather protection while maintaining your view.



BLIND VARIATIONS

FREE HANG BLINDS

Maximum Width: 5100mm Maximum Drop: 4000mm



Free Hang Blinds can be held down at the bottom of the blind. No side support is provided.

- Operation: Crank or Motorised
- Crank and Handle Colour: White or Black
- Bracket: White, Black or Stainless
- · Section Colour: White, Black, Putty, Bronze and Midnight
- Hold Downs: Steel collapsible with snap hook or tie down straps.
 (2,3 or 4)
- Top Finish: Exposed Brackets, Recess Fascia or Full Cassette


CHANNEL X

Maximum Width: 4000mm Maximum Drop: 3400mm









Putty

Channel X Blinds are supplied with a side Channel System.

• Operation: Crank or Motorised

• Crank and Handle Colour: White or Black

• Bracket: White, Black or Stainless

• Section Colour: White, Black, Putty, Bronze and Midnight.

 Hold Downs: Centre lock or Centre lock and Swivel hold downs (blinds wider than 3000mm)

• Top Finish: Exposed Brackets, Recess Fascia or Full Cassette